

Timber Bi Fold

Step 7 - Upright Stop Installation

Use the same fixing method you used for the bottom stop in Step 5.

To position the upright stops please close and lock the doors shut. Slide a 6mm packer between the door and the BOTTOM stop as a reference. If the 6mm packer is slightly tight you can sand it until it is able to slide in. Now place the 6mm packer between the door and stop at each fixing point so that the gap feels the same as the bottom stop gap. Continue to fix and plug as set out in Step 5.